



Construction Components

Component Number	Component Description	Position in Vehicle	Coordinate Location
1	ABS/DIFFERENTIAL LOCK CONTROL UNIT	7cQ	AB 73-76
2	ALARM SYSTEM CONTROL UNIT	7cM	OP 67/68
3	ALARM SYSTEM RELAY	8dN	LM 62/63
4	ALARM SYSTEM ADDITIONAL CONTROL UNIT	8dN	OP 64/65
5	OUTSIDE TEMPERATURE SENSOR	2/3dQ	G 31
6	ACCELERATING SENSOR	10eQ	K 73
7	BOOSTER	11eK	FG 62/63
8	RECEIVER FOR RADIO BERLIN	7cL	C 66
9	SUPPRESSOR FOR RADIO BERLIN	11eK	A 62
10	SUPPRESSOR FOR RADIO	8dO	C 62
11	SWITCHING UNIT EX (M193)	8dN	P 28-30
12	EZK CONTROL UNIT	7dL	L 82-84
13	REAR WINDOW WIPER RELAY	18cO	OP 17
14	HIGH PRESSURE AND LOW PRESSURE SWITCH	2dM	P 32

15	AIR CONDITIONING SYSTEM CONTROL UNIT	8cN/O	AB 34-36
16	COOLANT FAN FINAL STAGE	1cN	O 39/40
17	COOLANT FAN CONTROL UNIT	10eK	MNO 39/40
18	COOLING WATER PRESSURE SWITCH	5cM	MN 29/30
19	COOLING WATER TEMPERATURE SWITCH	6cM	MN 29
20	BULB CONTROL UNIT	7cL	NO 1
21	IDLE SPEED COADJUSTMENT POTENIOMETER	7dL	OP 88
22	LH JETRONIC CONTROL UNIT	7dL	J 87-89
23	SOLENOID VALVE LOCK DIFFERENTIAL	17dQ	C 72
24	SOLENOID VALVE (ADDITIONAL AIR CONDITIONER)	10eM	F 38
25	OIL LEVEL SWITCH	3eN/O	O 26
26	OIL TEMPERATURE SWITCH (M249)	13eO	P 35/36
27	PUMP LOCK DIFFERENTIAL	17dQ	B 77/78
28	PUMP RELAIS LOCK DIFFERENTIAL	16dO	B 79/80
30	CONTROL FOR ADDITIONAL AIR CONDITIONER	12dN	EF 39/40
31	TIRE PRESSURE CONTROL UNIT	7cP	K 76-78
32	SEAT MEMORY CONTROL UNIT LEFT	10dP	K-O 57
33	SEAT MEMORY CONTROL UNIT RIGHT	10dM	K-O 57
34	MIRROR MEMORY CONTROL UNIT	7cQ	O 54-57
35	CRUISE CONTROL CONTROL UNIT	7dN/O	AB 89/90
36	FREEZING PROTECTION SWITCH AIR CONDITIONER	7cM	FG 31
37	RESISTOR INSTRUMENT LIGHTS	7eP	DE 21/22
38	WARNING BUZZER	8cP	D 30
39	WASHING FLUID LEVEL SWITCH	6cL	M 29
40	RESISTANCE FROUP FOR BLOWER	7cL/M	KL 31/32
41	RESISTANCE GROUP FOR ADDITIONAL AIR CONDITIONER	12dO	HJ 37/38
42	TIME RELAY	8dN	P 23-25
43	CENTRAL ELECTRIC	7dM	Passenger's Footwell/Firewall
44	IGNITION CIRCUIT CONTROL CONTROL UNIT	7dL	HJ 81/82

Ground Points

Component Number	Component Description	Position in Vehicle
MP I	BODY FRONT LEFT	1cO
MP II	BODY FRONT RIGHT	2cM
MP III	WHEEL HOUSING WALL FRONT RIGHT	3cM
MP IV	STEERING CONSOLE	8cP
MP V	FIREWALL	8dM
MP VI	BODY REAR	16dO
MP VII	GROUND STRAP BATTERY	18dO
MP VIII	ENGINE POWER	6cO
MP IX	ENGINE ELECTRONICS	6cN
MP X	WHEEL HOUSING LEFT OUTER	3dQ
MP XI	WHEEL HOUSING RIGHT INNER	5cM
MP XII	WHEEL HOUSING LEFT INNER	5cP